




Disabling the Acoustic Echo Canceller

To disable the acoustic echo canceller for the sound source connected to the Line In port on your LifeSize Room system, follow these steps:

1. Ensure there are no calls in progress.
2. Navigate to the main screen by pressing the **Call**  button on the remote control.
3. Using the remote control, press the **LEFT ARROW** and **9 1 1** to navigate to the **Reserved Preferences** screen.
4. Enter the administrator password and press **OK**. The default password is 1 2 3 4.
5. Select the **Miscellaneous** button and press **OK**.
6. Select *Disabled* for the **Line In Acoustic Echo Canceller** preference if you wish to turn off the AEC for the microphones connected to the Line In port.
7. Press the **Call**  button to return to the main screen or use the  button to exit the **Reserved Preferences** screen.